


## MEASURING FOR PLEATED SHADES

## CHOOSE A MOUNT TYPE:

### **INSIDE MOUNT**



- Mounted inside your window's frame
- · Provides a clean, built-in look
- Leaves attractive woodwork exposed
- There is a ¾" minimum amount of space needed for this mount type. We call this measurement the minimum depth requirement.


### STEP 1

Because not all windows are perfect rectangles, we recommend measuring the window in 3 places to get your width: across the top, middle and bottom (see diagram above). Round all measurements to nearest ½". Take smallest number. This is your ordering width. We will make the necessary deductions (approx. ½"–¾")

## STEP 2

Finding the length is a similar process, measuring the length of the window in 3 places on the window: left, center and right. Round all measurements to nearest 1/2". Take largest number. This is your ordering length.

#### **OUTSIDE MOUNT**



- Mounted outside the window's frame
- Provides a taller, more dramatic appearance
- There is no minimum depth requirements

#### STEP 1

Measure the width of the area you wish to cover. If space allows we recommend adding 2-3'' (1-1½" each side) to this measurement to help eliminate light seepage. This is your ordering width and will be the overall measurement of the shade.

## STEP 2

Measure the height of the area you wish to cover. This is your ordering length.



# MEASURING FOR PLEATED SHADES

## DEPTH REQUIREMENTS

OPTIONS	Minimum Depth Required For Secure INSIDE MOUNT	Minimum Depth Required For Flush INSIDE MOUNT	Minimum Space Required For OUTSIDE MOUNT
Cord Lock	5/8"	23/8"	5/8"
Continuous Loop	7/8"	21/4"	13/4"
Cordless	7/8"	21/4"	13/4"
TDBU	5/8"	23/8"	5/8"
Multiple on 1 Cord Lock	5/8"	23/8"	5/8"
Multiple on 1 Continuous Loop	7/8"	21/4"	13/4"
Battery Motor	11/8"	21/4"	13/4"
Plug-In/Hardwired Motor	1½"	23/4"	13/4"