



# HOW TO MEASURE ROLLER & SOLAR SHADES


NEED HELP?

OUR EXPERTS ARE AVAILABLE TO HELP.

800.754.1455 | design@theshadestore.com  
Live Chat | Video Consultation  
Schedule Free Professional Measurement

## CHOOSE A MOUNT TYPE

### INSIDE MOUNT



- Mounted inside your window's frame
- Provides a clean, built-in look
- Leaves attractive woodwork exposed
- 3/4" minimum depth is required to do an inside mount

#### STEP 1: MEASURE THE WIDTH

Measure the width at the top inside the window frame. This is your ordering width. We will take a small deduction (approx. 1/8") so the shade fits in properly.

WIDTH	RECORD MEASUREMENT (1/8" INTERVAL)
A: TOP	

#### STEP 2: MEASURE THE LENGTH

Finding the length is a similar process measure the length of the window in 3 places on the window: left, center and right. Round all measurements up to nearest 1/8". The largest of the 3 measurements is your ordering length.

LENGTH	RECORD MEASUREMENT (1/8" INTERVAL)
B: LEFT	
C: CENTER	
D: RIGHT	

\*Largest of the 3 length measurements is your ordering length.

#### STEP 3: MEASURE THE DEPTH

Measure the depth at the top of the inside window casing. We want to ensure you have enough depth to securely do an inside mount, as well as understand if you're interested in a flush mount (where the product does not protrude from the window frame). The depth of the product varies based on control type and options. 3/4" minimum depth is required to do an inside mount. Contact our Design Consultants for additional information.


DEPTH	RECORD MEASUREMENT (1/8" INTERVAL)
E: DEPTH	

Material Note: On all Roller & Solar Shades, the actual material width is always a little less than the ordering width to allow for brackets. How much less depends on the control type you select.

CONTROL	DIFFERENCE IN WIDTH (amount material width is less than bracket-to-bracket width)
CONTINUOUS LOOP	1 1/4"
CORDLESS	3/4"
MOTORIZED	1 3/8" - 1 5/8" (depending on width of shade)

Click [HERE](#) to watch how to measure for inside mount Roller & Solar Shades.

### OUTSIDE MOUNT



- Mounted outside or on top of the window's frame
- Provides a taller, more dramatic appearance
- There is no minimum depth requirement

#### STEP 1: MEASURE THE WIDTH

Measure the width of the area you wish to cover. If space allows we recommend adding 2-3" (1 - 1 1/2" each side) to this measurement to help eliminate light see page. This is your ordering width and will be the overall measurement of the shade.

WIDTH	RECORD MEASUREMENT (1/8" INTERVAL)
A: TOTAL WIDTH TO COVER	

\*This is your ordering width.

Workroom Notes: For outside mount shades with upholstered valances, please note the valance will be 1" wider than your ordered width due to returns.

#### STEP 2: MEASURE THE LENGTH

Measure the height of the area you wish to cover. This is your ordering length.

LENGTH	RECORD MEASUREMENT (1/8" INTERVAL)
B: TOTAL HEIGHT TO COVER	

\*This is your ordering length.

Click [HERE](#) to watch how to measure for outside mount Roller & Solar Shades.