


MEASURING FOR CORNICES

CHOOSE A MOUNT TYPE:

INSIDE MOUNT



- Mounted within the window frame or wall-to-wall
- Provides a clean built-in look
- If window frame isn't deep enough, please select outside mount

STEP 1

Measure inside width at the top of the window where cornice is to be mounted. If there are any size variations, use the smallest measurement.

Note: Inside mount Cornices do not come with returns.

STEP 2


Determine the height you would like the cornice to be. This will be your ordering height.

STEP 3


Determine the depth you would like your cornice to be—this will be the ordered depth of Cornice.

STEP 4

If you are mounting a product under the Cornice, reference the depth requirements chart.



OUTSIDE MOUNT



- By far the most common mount type for cornices
- Mounted to the wall, ceiling or molding surface surrounding the window
- Often used to make the window appear taller
- Also used to hide shade/blind when raised

STEP 1

Measure the width of the area you wish to cover. If space allows, we recommend adding 2-3" to this measurement.

Note: This will be the inside width of the Cornice. Outside mount cornices come with returns on each side, adding 1½" to total overall width.

STEP 2


Determine the height you would like your Cornice to be. This will be your ordering height.

STEP 3

Determine the depth you would like your Cornice to be—this will be the ordered depth of cornice. The overall outside depth (a.k.a Return) will be ½" deeper due to face of Cornice.

STEP 4

If you are mounting a product under the Cornice, reference the depth requirements chart.



DEPTH REQUIREMENTS

CLEARANCE/ ORDERING DEPTH	FACE THICKNESS	OVERALL DEPTH <small>A.K.A RETURN</small>	Minimum Depth Required For Secure INSIDE MOUNT	Minimum Depth Required For Flush INSIDE MOUNT	Minimum Space Required For OUTSIDE MOUNT
1½"	½"	2"	1"	2"	2¼"
2½"	½"	3"	1½"	3"	3"
3½"	½"	4"	2"	4"	4"
5½"	½"	6"	2½"	6"	4½"
7¼"	½"	7¾"	3"	7¾"	6"

DON'T HAVE TIME TO MEASURE? WE'LL DO IT - FREE.

Call 800.754.1455 or visit theshadestore.com/measure to schedule a free professional measurement.