




HOW TO MEASURE:

IT ALL STARTS WITH THE MOUNT TYPE

How do you want to hang your Roller/Solar Shade? Inside the window frame? Outside the window frame? There are benefits to each and some important differentiators to learn.

OPTION 1: FOLLOW OUR STEP-BY-STEP INSTRUCTIONS

INSIDE MOUNT



- Mounted inside your window's frame
- Provides a clean built-in look
- Leaves attractive woodwork exposed
- There is a ¾" minimum amount of space needed for this mount type. We call this measurement the minimum depth requirement.

STEP 1

Measure the inside width at the top of your window (to the nearest 1/8"). This is your ordering width. We will make the necessary deductions (approx. 1/8").


STEP 2

Measure the height at 3 locations – the left side, middle and right side. Record the largest of the 3 measurements. This is your ordering length.


Workroom Notes:

- Roller/Solar Shade materials will be approximately
- 1/8" narrower than your ordering width to allow
- For brackets. If concerned over resulting light gap, please select outside mount.

INSIDE MOUNT "NON-FLUSH"




Ceiling/Top




Side

INSIDE MOUNT "FLUSH"




Ceiling/Top



Side

OUTSIDE MOUNT



- Mounted outside or on top of the window's frame
- Provides a taller, more dramatic appearance
- There is no minimum depth requirement

STEP 1

Measure the width of the area you wish to cover. If space allows we recommend adding 3-4" (1½"-2" each side) to this measurement to help eliminate light seepage. This is your ordering width and will be the overall measurement bracket to bracket.


STEP 2

Measure the height of the area you wish to cover. This is your ordering length.


Workroom Notes:

- Your shade fabric will be 1/4" narrower than the measurement you provide to allow for brackets. If you need the material to cover a specific width (i.e. for mounting the shade on a door), add 1/4" to the desired fabric width and this will be your ordering width.
- For shades with upholstered valances, please note the valance will be 1" wider than your ordered width due to returns.


OUTSIDE MOUNT TO FRAME MOUNT



OUTSIDE MOUNT TO WALL



CEILING MOUNT



OPTION 2: VIEW OUR "HOW TO" VIDEO ONLINE

GO TO: theshadestore.com/measure

OPTION 3: HIRE A PROFESSIONAL TO MEASURE

We have put together a national network of independent measure & install professionals. Simply go online, visit a showroom, or give us a call – and we can match you to a local pro. Once the professional measures, they'll send us a copy of your measurements, and we'll contact you to put your order together. This same professional can also install your window treatments. It's that simple!

GO TO: theshadestore.com/findinstaller
Type in zip code and get matched today!

DEPTH REQUIREMENTS

OPTIONS	Minimum Depth Required For Secure INSIDE MOUNT	Minimum Depth Required For Flush INSIDE MOUNT (Ceiling/Top)	Minimum Depth Required For Flush INSIDE MOUNT (Side)	Minimum Space Required For OUTSIDE MOUNT
Designer Bracket*	¾"	2¼"	3"	2¼"
Designer Bracket Extension*	¾"	2¼"	3¾"	2¼"
Upholstered Valance*	1¼"	3"	N/A	3"
Small Metal Valance	1¼"	2¾"	N/A	1¼"
Medium Metal Valance	1¼"	3⅝"	N/A	2"
Large Metal Valance	1½"	4⅜"	N/A	2¼"
Cordless	2"	2½"	N/A	1⅞"
Cordless with Upholstered Valance*	1¼"	3"	N/A	3"
Cordless with Metal Valance (Medium)	1¼"	3⅝"	N/A	2"
Cordless with Metal Valance (Large)	1¼"	4⅜"	N/A	2"
Battery Motor	¾"	2¼"	3"	1"
Battery Motor with Upholstered Valance*	1¼"	3"	N/A	3"
Plug-In/Hardwired Motor* (shades up to 144" wide)	¾"	2¼"	3" 3¾"	1⅜"
Plug-In/Hardwired Motor* (shades 144½" - 156")	¾"	2¼"	3" 3¾"	1⅜"
Plug-In/Hardwired Motor with Upholstered Valance* (shades up to 144" wide)	1¼"	3¼"	N/A	3"
Plug-In/Hardwired Motor with Upholstered Valance* (shades 144½" - 156")	1¼"	3¼"	N/A	3"
Double Vertical Bracket	¾"	3½"	N/A	N/A
Double Vertical Bracket with Upholstered Valance*	1¼"	4"	N/A	3"

Workroom Notes:

- *Shades over 90" W and/or 100" L may require larger brackets or valances.
- All shades in same room will have same size brackets and valances.
- Cordless control option not available with small metal valance.